

TTC-NC05TZ/NPW/V2(RB) CPU Support

For AMD AM2/AM2+/AM3/AM3+/AM4/FM1/FM2/FM2+

For Intel LGA 775/1150/1151/1155/1156/1366/2011

For AMD AM2/AM2+/AM3/AM3+/AM4/FM1/FM2/FM2+

For AMD Socket AM2/AM2+/AM4 all series

For AMD Socket AM3

·AMD Sempron™ all series

·Quad-Core AMD Opteron™ all series

·Phenom™ II X6 Black Edition all series

·Phenom II X2 Black all series

·Phenom II X4 Black all series

·Phenom™ II X6 all series

·Phenom™ II X4 805~955/B93~B95

·Phenom™ II X3 all series

·Phenom™ II X2 all series

·Athlon™ II X4 all series

·Athlon™ II X3 all series

·Athlon™ II X2 all series

For AMD Socket AM3+

·FX 4-Core Black Edition all series

·FX 6-Core Black Edition all series

·FX 8-Core Black Edition FX-8120~8370

For AMD Socket FM1/FM2/FM2+ all series

For Intel LGA 1366 all series

For Intel LGA 1156/1155/1150/1151 all series

For Intel LGA 2011

·Core™ i7-3820~3960X · 4820K~4960X

For Intel LGA 2066

·Core™ i5-7640X · i7-7740X

For Intel LGA 775

· Core2 Duo all series

· Core2 Extreme up to ~ QX9650/X6800

· Core2 Quad all series

· Pentium D up to ~ 960

· Pentium Dual Core all series

· Pentium Extreme all series

· Pentium 4 up all series

· Celeron all series