## TTC-NC85TZ(RB) CPU Support

For AMD AM2/AM2+/AM3/AM3+/FM1/FM2/FM2+ For AMD Socket AM2/AM2+ all series For AMD Socket AM3 ·AMD Sempron<sup>™</sup> all series ·Quad-Core AMD Opteron<sup>™</sup> all series ·Phenom™ II X6 Black Edition all series ·Phenom II X2 Black all series ·Phenom II X4 Black all series ·Phenom<sup>™</sup> II X6 all series ·Phenom™ II X4 805~955/B93~B95 ·Phenom™ II X3 all series ·Phenom™ II X2 all series ·Athlon™ II X4 all series ·Athlon™ II X3 all series ·Athlon™ II X2 all series For AMD Socket AM3+ ·FX 4-Core Black Edition all series ·FX 6-Core Black Edition all series ·FX 8-Core Black Edition FX-8120~8370 For AMD Socket FM1/FM2/FM2+ all series For Intel LGA 1366 all series For Intel LGA 1156/1155/1150/1151 all series For Intel LGA 2011 ·Core™ i7-3820~3960X \ 4820K~4960X For Intel LGA 775 · Core2 Duo all series · Core2 Extreme up to ~ QX9650/X6800 · Core2 Quad all series · Pentium D up to ~ 960 · Pentium Dual Core all series

- · Pentium Extreme all series
- · Pentium 4 up all series
- $\cdot$  Celeron all series